

Keep feed fresh. Stale feed will not be consumed. Feed wastage will be kept to a minimum by initially filling the feeder with as little as 1/4 cup per feeding. Gradually increase the amount fed as required. This feeder can also be used to reduce stress during the transition from farrowing to nursery. A smooth transition is aided by moving the feeder along with the pigs from the farrowing facility to the nursery and placing the feeder next to your nursery feeder. This feeder must be removed from the nursery pen 3 to 5 days after weaning. NOTE: Use a thread locking compound on the threads of the pegs before insertion.

Model FPCR1
EZ-SERV Creep Feeder

HAWKEYE STEEL PRODUCTS, INC.
Houghton, Iowa USA ISEZ
